Module m02: Adding IP and Device Drivers in XPS

Version for EDK 6.3i Jan/06/2005

## Acknowledgement

This lab is derived from a Xilinx lab given at the University of Toronto EDK workshop in November 2003. Many thanks to Xilinx for allowing us to use and modify their material.

### Goals

- Use Xilinx tools to add to the basic MicroBlaze system that was built in Module 1. A primary goal of this lab is to understand more details about adding IP into the system without Base System Builder and using device drivers.
- The General Purpose I/O (GPIO) IP core is used in this lab together with the associated device driver. The GPIO will be added to the project and used to turn on and off User LED 0 on the board. You will manipulate the state of the LED from XMD and by using a program.
- Get an introduction to the use and structure of driver code.

## Requirements

Module 1 on building a base system.

# Preparation

- 1. The GPIO is a simple parallel I/O port that has similar functions to the PIT used on the GIZMO board. You can have from 1 to 32 input/output ports, which corresponds to the processor having a 32-bit bus. If you use fewer than 32 ports, the advantage of working in the FPGA synthesis environment is that you will only instantiate logic for the number of ports that you require.
  - If you are on an installed system, find the overview of the OPB GPIO in the Processor IP Reference Guide. The Guide is provided in the EDK Online Documentation. The location of the documentation was described in Module 1. In the Guide you will find a link to the data sheet. Familiarize yourself with how this block works.
- 2. Also, only available via the documentation tree of an installed system is the Device Driver Programmer Guide. Xilinx provides device drivers so that the user may create applications quickly and easily. The Device Driver Programmer Guide documents many details of the device drivers and software infrastructure. You should get familiar with this section as you may eventually need to write your own drivers. In this lab you will be required to modify some code to properly use the existing drivers.
- 3. You will start modifying code in this lab. If you are not familiar with any source code control system, you can quickly learn one by doing "man resintro" on any unix system. Using such a system is highly recommended and just good practice. You will need to run the commands from a window connected to one of the ugsparcs. There is an ssh window in the Courseware folder.
- 4. You will need another 15MB of disk space. Limits will be adjusted once the final class list is known. You can "clean" the files created in Module 1 via the Tools menu to save some space.

Module m02: Adding IP and Device Drivers in XPS

## **Background**

Processor IP is an integral part of a System-On-Chip (SOC) system. Xilinx provides a variety of processor IP cores that can quickly and easily be integrated into a system using XPS.

This module builds from Module 1 and assumes that the user has completed Module 1. A basic understanding of the EDK tools should have been gained from Module 1.

### Setup

- 1. Copy the XPS project directory (lab 1 folder) of the previous lab and rename the copy to "lab2". This will be the working project directory for this lab.
- 2. Start XPS by selecting Courseware->Xilinx 6.3i->Xilinx Embedded Development Kit 6.3->Xilinx Platform Studio from the Windows desktop.
- 3. From the initial startup screen, select Open a Recent Project and click OK. Browse to the system.xmp file of in the lab2 directory. Click Open to open the project. This is the project you completed in Module 1.

#### Adding A GPIO With User LED 0

- 4. Select the Project menu followed by the Add/Edit Cores submenu. A dialog box is displayed. Examine all the tabs to look at the various aspects of the system that you have already built. Think about how hard it would have been to do this from scratch! Having validated (tested) ready-to-use function blocks can significantly improve your design cycle.
- 5. From the Peripherals Tab of the dialog box, scroll to the opb\_gpio IP core in the box on the right side of the dialog box. Select the opb\_gpio and click Add to add it to the system that is displayed on the left side of the dialog box.
- 6. From the Addresses tab, set the base address of the opb\_gpio to 0x80040000. The base address is the 1st address that will be decoded by the peripheral on the On-chip Peripheral Bus (OPB).
  - Set the Size to be 512. This will automatically set the High Address of the device to 0x800401ff, which uses the minimum amount of memory space as displayed for the device.
  - What do you expect the tool to be doing with this information?
- 7. Select the Bus Connections tab of the dialog box. The opb\_gpio is displayed as the last row in the table of peripherals on the buses. The table rows show the peripheral bus interfaces in the design and the table columns show the buses to which each peripheral interface may be attached. Clicking on a table entry will allow the peripheral to be attached to the bus. The entry is either 'M' or 's' with 'M' being a master on the bus and 's' being a slave on the bus. Select the opb\_gpio to be a slave on the mb\_opb.
- 8. Select the Parameters tab of the dialog box. Choose the opb\_gpio instance in the drop-down menu, of the dialog box. Select the Open PDF Doc button on the upper right corner to open the specification for the IP. Review the parameters that can be set and signals that are to be input and output based on the application.
  - Parameters are implemented in the IP using VHDL generics. This feature of VHDL is a large advantage for IP that must fit many different applications.
- 9. Switch back to the Parameters tab in XPS. Select the C\_GPIO\_WIDTH parameter and click Add to add it to the parameters that will be changed on the left side of the dialog box. Edit the value in the left side and change it from 32 to 1 such that there is only 1 bit of general purpose I/O. The general purpose I/O will be an output to control an LED on the board.

#### Module m02: Adding IP and Device Drivers in XPS

10. Select the Ports tab of the dialog box. In the box on the right side, scroll down to the opb\_gpio instance and select the GPIO\_IO signal of the opb\_gpio instance. Click Add to cause the signal to appear in the signal list on the left side of the page.

Select the newly added signal on the left side of the page and click the button Make External. This should add the GPIO\_IO signal to the list of External Port Connections in the upper left of the dialog box

What do you expect the tool to do with this information?

Notice that the GPIO signal is external such that it will be pinned out of the design and connected to a pin of the FPGA. That pin will be connected to the LED driver.

11. Click the OK button of the Add/Edit Cores dialog box to accept all the changes that have been made to add the GPIO IP to the system.

### Building The System With GPIO

- 12. Select the Options menu and the Project Options submenu. Select the HDL and Simulation tab. If it is not already set, select Verilog as the HDL type.
- 13. Select the Tools menu and the Generate Netlist submenu. This will take a few minutes to complete. This step is updating the system and synthesizing it to use the GPIO IP. When it completes, it is not yet ready to put in the FPGA because it is only a netlist, which is only a description of the logic elements and how it is connected. A bitstream will need to be generated by doing a place and route of the design for the FPGA.
- 14. Open the system.ucf file located in the data directory of the XPS project. This file contains the design inputs and outputs to specific pins of the FPGA. Edit the UCF file to connect bit 0 of the GPIO\_IO signal to User LED 0 by adding the line

Net opb\_gpio\_0\_GPI0\_IO LOC=B27;

and save the file.

The net name is the same as the signal you added to the Ports tab of the Add/Edit Cores dialog. Pin B27 of the FPGA connects to User LED 0. The pins of the FPGA are described in the Multimedia Board UserGuide which is available on the UofT EDK page. You can find pin B27 on page 23. See if you can find the pin on the Multimedia Board Schematics available on the UofT EDK page. You will observe that the schematic is quite large. Use the Acrobat Find feature to look for the string user\_led. You should find it on two pages. One showing the pins of the FPGA and the other showing the connection to the LEDs. Remember how the LEDs are driven as a later step will ask you about this.

- 15. Right click on Project:mb0\_default in the Applications tab and select the Set Compiler Options submenu. A dialog box is displayed. Verify that the XmdStub mode of operation is selected and the Program Start Address is 0x500. This will build the ROM monitor stub, called XmdStub, into the software and hardware so that debugging can be done. Executable mode assumes that the software has already been debugged and executes it on reset.
- 16. Select the Tools menu followed by the Download submenu. This will run the ISE place and route tools to create a bitstream, then download the bitstream to the target board. This will take a few minutes.

#### Testing The GPIO In Hardware

16. After the hardware and software have successfully downloaded, use XMD to test the system to ensure that the GPIO is working. Reads and writes of the GPIO registers can be done using the read (mrd) and write (mwr) memory commands of the XMD because the registers are memory mapped. The

Module m02: Adding IP and Device Drivers in XPS

GPIO data sheet states that the GPIO\_DATA register is at address 0x00 and the GPIO\_TRI register is at 0x04. Previously, you set the base address of the GPIO to 0x80040000. Add these numbers to determine the register addresses.

The tri-state register of the GPIO must be set to zero such that the LSB of the register is an output as described in the GPIO data sheet. A zero must be written to the GPIO DATA register to turn on the User LED. Can you explain this? Recall what you saw on the schematics.

#### Adding Software To Use GPIO

- 17. Layer 1 drivers are high-level drivers. Their interfaces are defined in <driver>.h files. Each file includes the low-level (layer 0) driver interface defined in <driver>\_l.h. The layer 1 driver has a larger memory footprint and robust error checking that is not part of the layer 0 driver. The high level driver also supports more device features and interrupt driven I/O. Each function of the layer 0 driver takes the base address of the device as the first argument. Each function of the layer 1 driver takes an instance pointer as the first argument.
- 18. Remove the lab1.c source file from the previous lab by selecting it under Sources in the Applications tab and pressing delete.

Add the source file lab2a.c by right clicking on sources in the Applications tab, selecting Add File, and navigating to the code directory of your project. Before making changes to the file, a good practice is to use a source code control system to help you archive the multiple versions of your code as you change it. Use RCS, or another system, to archive the original file before you change it.

Reference the device driver documentation in the Driver Reference Guide to determine the names of the device driver header files. The Driver Reference Guide is available in the EDK Online documentation. You can also browse to the drivers included in the XPS project by looking in the microblaze\_0/libsrc subdirectory of the project. First, note that the files are copied there when you select Tools->Generate Libraries from the menus.

Make the appropriate changes to the source file such that it will compile. There are a number of places marked with <TO BE DONE xxx> that need to be modified. Some of the values can be found by referencing the xparameters.h file for system-wide constant definitions. This header file is listed under the microblaze\_0 instance in the System tab of XPS as the Generated Header. Double click the Generated Header item to view the file in the XPS editor.

This source code uses the GPIO driver to turn on and off the LED on the board at a visible rate. Save and compile the program. Connect to XmdStub with XMD and download the executable using XMD. Open XILINXPORT and use the Software Debugger to verify that the code works correctly. Remember to avoid using the Run submenu of the Run menu and the running man icon to run the program, due to a bug with EDK 6.3i.

#### Other things to consider

- 1. What version of the MicroBlaze processor is being used? (hint: look in Project->Add/Edit Cores)
- 2. What is the base address of the UartLite peripheral (its instance name is RS232)?
- 3. What is the instance name of the opb\_mdm peripheral?
- 4. What is the net name used for the system clock in the design?
- 5. What is the name of the UartLite receive data signal? Is the external reset signal active high or active low? (hint: look at the parameters for the LMB and OPB bus controllers)

#### Look At Next

Module 3: Drivers, IP, and Interrupts